

PROVISIONAL DATA

# TILEKLEEN

## Tile Cleaner

**TILEKLEEN** is a clear liquid solution containing surfactants, chelating agents and inhibited acid. It is used to remove dirt and hardened cement grout from the surface of tiles, terrazzo and masonry floors. It is safe to use and does not penetrate and weaken masonry substrate unlike strong acids.

**TILEKLEEN** can be use on the following surfaces:

Glazed, unglazed ceramic tile, mosaic, quarry tile, granite and terrazzo. (patch test is always recommended).

### DIRECTION FOR USE

#### PATCH TEST

Before using **TILEKLEEN**, it is highly recommended to do a patch test. This will determine whether the cleaner is suitable and whether there are any sealers present. First, pour a small amount of **TILEKLEEN** directly on a small section of the floor. Let it stand for 15-20 minutes during which time, observe for bubbling in the grout joints. If it does not, a sealer is present and has to be removed first(consult ACI for additional recommendations). Using a stiff-bristled brush, remove the loosened grime and rinse with clean potable water. Since colored grout appears darker when wet, allow test area to dry completely before checking the result.

#### APPLICATIONS

**TILEKLEEN** is ready to use and does not require dilution. Simply pour the cleaner onto the surface, allow it to stand for 15-20 minutes, and then scrub clean with a nylon pad or stiff-bristled brush. Finally, rinse with clean, potable water. On large areas, a floor machine with a scrubbing brush will give the best result.

#### LIMITATIONS

**TILEKLEEN** is not suitable for marbles. It may remove the coloring from some types of colored grout. It may not be suitable for deep cleaning contoured ceramic tile and dried grease. It is not a maintenance cleaner since repeated usage over the same floor sections will diminish its effectiveness.

#### THEORETICAL COVERAGE

Approximately 14-20 square meters per liter depending on the porosity and condition of surface.

#### HEALTH AND SAFETY

**TILEKLEEN** contains mild acid. Always wear protective eye goggles, rubber hand gloves and coveralls when using. Refer to separate MSDS for additional information on safety precautions.

#### PACKING/SHELF LIFE

**TILEKLEEN** is available in 5 and 20 liter packing and has indefinite shelf life if stored in covered warehouse condition in sealed original containers

Revised: 15.01.2023

Technical information, data are to be considered as typical values and not sales specification. Actual measured values may vary due to factors beyond our control. Indications concerning function and application of the products are empirical. Although the information is believed to be accurate, there is no warranty by ISOLA. None of the recommendations becomes part of the warranted quality of the products. Due to the fact that the conditions of individual use are beyond ISOLA's direct and continuous control, ISOLA disclaims all responsibility in connection with the use of its products and does not warrant against any loss direct or consequential

**ISOLA SOLUTIONS W.L.L**

P.O. Box 530, Manama, Kingdom of Bahrain, Tel: 17784777, Fax: 17911422, Email: [isola@hajihassan.com](mailto:isola@hajihassan.com), web: [www.isolasolutions.com](http://www.isolasolutions.com)